



SPORTSMAN STEEL VAULTS

Clients: FBI, CIA, Homeland Security, US Secret Service

Welcome! Sportsman Vaults has been in business 40 years & has never had a vault door drilled open, pried open or lost to fire. We attribute our perfect track record to our Step-System Doors, 4-Barrel Relockers & 3/4" steel pry-proof frame. Our advanced innovation & 6000 DEGREE CONCRETE FIRE-PROOFING has earned us business with the FBI, CIA, Homeland Security & Secret Service.

Many Vault Doors and Vault Rooms to Choose From



ARMORY



CROWN



PHANTOM



FEDERALIST



MODULAR VAULT ROOMS

VAULT INSTALLATION - *First off, It's Easy!*

Step 1 - Build your vault door opening 3/8" taller and wider than your vault door. For example, if you're ordering an 80" x 36" x 8" vault door, your opening should be 80 3/8" tall x 36 3/8" wide x 8" deep.

Step 2 - When installing your Sportsman vault door make sure your door opening is straight & plumb. If you constructed your vault room with concrete blocks, make sure your cement blocks around door are filled with actual concrete.

Step 3 - Before you insert your vault door in your opening, squeeze a healthy amount of high-end fireproof coaxing 1" inside your concrete opening.

Step 4 - Insert your vault door in opening. Make sure you maneuver or press the frame flush against your front wall. Using a 5/8" concrete drill bit, drill thru the bolt hole openings into your concrete.

Step 5 - Set wedge anchors in the drilled holes and tap in place. Then snug the set anchors on each side of frame. Square the frame in the doorway by loosening and tightening the set anchors on each side of the frame. NOTE: do not over-tighten bolts. This may throw frame out of alignment.

Step 6 - Use 1/8" or 3/16" shim between the wall and the bottom of the hinge side of the frame if the door rubs against bottom frame. Once frame is square and door opens and closes without rubbing anywhere on vault, drill and set the remaining anchors and tighten them evenly around frame.

Step 7 - Open & shut door many times until you are certain the frame isn't being pulled out of alignment. Use high-temp fire coxing between the frame and your concrete wall. Also include coxing between threshold and floor.

URGENT: DO NOT OVER-TIGHTEN CONCRETE BOLTS DURING INSTALLATION. TURN BOLTS UNTIL LIGHTLY SNUG.

REMEMBER TO TELL YOUR INSTALLER TO PROPERLY SHIM DOOR ON EVERY BOLT HOLE.

Or just call us and we'll walk you through the whole installation process - 800-266-7150



ARMORY VAULT DOOR

Best Vault Door For Budget



80"x30"x8" - \$3795

80"x36"x8" - \$4095

80"x42"x8" - \$4495

**NEW - 6000 Degree Concrete fireproofing
- 4 x more fire resistant than fire board**

FREE QUOTE - CALL US

- 1 3/4" COMPOSITE DOOR - 75 MIN FIRE - Made in USA
- 6000 Degree Concrete Fireproofing - 4 x more fire resistant than fire board
- Overall Door Thickness - 4 1/2" Total
- 5-Prong Spindle Wheel - Removable
- Sargent & Greenleaf Lock - Digital Lock Available
- Silver or Gold Pin-Stripe
- Two Relockers - Brass-arm & Independent
- Texas Tech Tested Logo
- 1/4" 60 Rockwell Hardplate - In Front of Lock
- 14 Bolt Locking System
- Black or Brown Semi-Gloss Paint
- Texas Tech Certified Storm Door
- Lifetime & Fire Warranty
- Bullet-Proof Door & Inward Swing Available



Inward Swinging Armory Vault Door



Armory Vault Door Installed



Inward or Outward opening door available



Wide Armory Vault Door with Custom Lettering



Tactical Vault Door Interior



Pistol Holsters - Double Support



CROWN VAULT DOOR

1st Residential Vault Door Built like a Step Bank Vault Door



80"x30"x8" - \$4295

80"x36"x8" - \$4795

80"x42"x8" - \$5295

**1/2" SOLID STEEL CHEST PLATE
2" STEP DOOR - 2 HOUR FIRE
6000° CONCRETE FIRE-PROOFING
FREE QUOTE - CALL US**

- 2" Step System Door - 2 Hour Fire
- Overall Door Thickness - 5 1/2" Total
- 3/4" Steel Pry-Resistant Frame - Thickest in USA
- **6000 Degree Concrete Fireproofing - 4 x more fire resistant than fire board**
- Sargent & Greenleaf Lock - Digital Lock Available
- Semi Gloss Paint - 8 Colors
- Silver or Gold Pin-Stripe
- Texas Tech Certified Storm Door
- 1/2" Hardplate - 18 BOLT SYSTEM
- Internal Release - Panic Room Handle
- 5-Prong Banker Wheel
- Custom Initials
- 2 Spring-Loaded Relockers
- 2 Palusol® Expand Gaskets
- Bullet-Proof Door & Inward Swing Available



NEW
Wood Grain finish
Vault Door



NEW
Wood Panel Door finish
Vault Door



Inward Swinging Door
Custom Initials



Add Your or Initials
to your Vault Door



Crown Vault Door
Hidden Vault Room.



PHANTOM VAULT DOOR

Best Vault Door For Security & Fire - 1" Steel Chest Plate

80"x30"x8" - **\$5395**

80"x36"x8" - **\$5995**

80"x42"x8" - **\$6495**



NEW - 6000 Degree Concrete Fireproofing
- 4 x more fire resistant than fire board
FREE QUOTE - CALL US

- 3" Jig-Saw Door - 2.5 Hour Fire
- Overall Door Thickness - 6 1/2" Total
- 3/4" Steel Frame - Thickest Pry-Resistant
- **6000 Degree Concrete Fireproofing - 4 x more fire resistant than fire board**
- 2 Palusol® Expand Gaskets
- 3/4" Solid 60rw Hardplate
- Banker Handle
- 8 Custom Colors
- Silver or Gold Artisan Pin-Striping
- 4 Barrel Relockers - No Drill Outs in 36 Yrs.
- Internal Release - Panic Room Handle
- 18 Locking Bolt - Life Warranty
- Texas Tech Certified Storm Door
- Ballistic Steel & Inward Swing Available



NEW
Wood Grain finish
Vault Door



NEW
Wood Panel Door finish
Vault Door



Inward Swinging Door
Custom Initials



Add Your or Initials
to your Vault Door



Crown Vault Door
Hidden Vault Room.



FEDERALIST VAULT DOOR

Best Vault Door in Commercial Industry - 1" Steel Door



80"x30"x8" - **\$7695**

80"x36"x8" - **\$8795**

80"x42"x8" - **\$9295**

NEW - 6000 Degree Concrete Fireproofing
- 4 x more fire resistant than fire board

FREE QUOTE - CALL US

- 3" Step System Door - 2 Hour Fire
- 3/4" Steel Bolt Protectors
- 1" Solid Steel Door - USA Steel
- 1" Steel Chest Plate
- **6000 Degree Concrete Fireproofing - 4 x more fire resistant than fire board**
- 2 Palusol® Expand Gaskets
- 1" 60rw Hardplate
- 5-Prong Banker Handle
- Sargent & Greenleaf Lock - Biometric Lock Available
- 8 Custom Colors
- 4 Barrel Relockers - 1" x 5" Solid Steel
- Internal Release - Panic Room Handle
- 18 Locking Bolt - Texas Tech Certified Storm Door
- Life Warranty - Lock & Fire
- Ballistic Steel & Inward Swing Available



Tactical Wall Panels

Tactical Vault Room Interiors





MODULAR

VAULT ROOM

Convert Your Closet into a Walk-In Gun

Vault Prices Start - \$22,995



Converting a closet or extra room into a fireproof gun room is the latest craze. Why buy a large gun safe for big bucks when you can get create a walk-in gun vault for the same cost. Easy-to-install 1/4" thick - 12" wide panels allow this room to be bolted together in one day. Ballistic grade steel & custom sizes are available. **Contact us for pricing - 800-266-7150**



TACTICAL

WALL PANELS

WEAPON STORAGE - GUN ROOM INTERIORS

Are you building an weapon's armory? If you're interested in high density weapon storage, our tactical storage panels are the perfect solution. Whether you're building an armory for the military, a government agency or your personal firearms collection, our tactical panel allows you to add, subtract or move gun storage accessories as you see fit. Call our Weapons Storage Experts to get a quote on your safe room interior today.





VAULT INSTALLATION GUIDE

First off, It's Easy!



Step 1 - Build your vault door opening 3/8" taller and wider than your vault door. For example, if you're ordering an 80" x 36" x 8" vault door, your opening should be 80 3/8" tall x 36 3/8" wide x 8" deep.

Step 2 - When installing your Sportsman vault door make sure your door opening is straight & plumb. If you constructed your vault room with concrete blocks, make sure your cement blocks around door are filled with actual concrete.

Step 3 - Before you insert your vault door in your opening, squeeze a healthy amount of high-end fireproof coaxing 1" inside your concrete opening.

Step 4 - Insert your vault door in opening. Make sure you maneuver or press the frame flush against your front wall. Using a 5/8" concrete drill bit, drill thru the bolt hole openings into your concrete.

Step 5 - Set wedge anchors in the drilled holes and tap in place. Then snug the set anchors on each side of frame. Square the frame in the doorway by loosening and tightening the set anchors on each side of the frame. NOTE: do not over-tighten bolts. This may throw frame out of alignment.

Step 6 - Use 1/8" or 3/16" shim between the wall and the bottom of the hinge side of the frame if the door rubs against bottom frame. Once frame is square and door opens and closes without rubbing anywhere on vault, drill and set the remaining anchors and tighten them evenly around frame.

Step 7 - Open & shut door many times until you are certain the frame isn't being pulled out of alignment. Use high-temp fire coaxing between the frame and your concrete wall. Also include coaxing between threshold and floor.

Or just call us and we'll walk you through the whole installation process.

CALL: 800-266-7150

Sportsman Steel Safe Company
6311 N. Paramount Blvd.
Long Beach, CA 90805